

WHEEL SHIELD INSTALLATION INSTRUCTIONS

FOR 2007-18 JEEP JK/JKU STOCK SPARE TIRE CARRIER AND WHEELS

Note: It is most helpful to have 2 people install the Wheel Shield.

STEP 1 - INSTALL BUNGEE STRAP



Lay your Wheel Shield face down on the supplied bubble wrap to protect the face. Thread the bungee cord through the D-Ring. It's a tight fit, so you may have to turn the hook end counter-clockwise through the D-Ring.



STEP 2 - INSTALL WEATHERSTRIPPING



Install 4 pieces of weatherstripping on opposite sides of the wheel face. These are used to help hold the Wheel Shield in place and

also provide some cushion between the Wheel Shield and the wheel. There are two different thicknesses that are supplied. Use whichever thickness gives the best hold and cushion for your particular wheel. You will also want to place them where they are hidden behind the Wheel Shield.

STEP 3 - REMOVE WHEEL CENTER CAP



Use a small screwdriver or even a butter knife to remove the center cap from the wheel. Use care to not damage your wheel or cap.



STEP 4 - FEED BUNGEE THROUGH CENTER HOLE



Insert bungee into the wheel center hole. Lift and have 1 person hold the Wheel Shield in place and open the rear cargo door.



STEP 5 - FEED THE BUNGEE THROUGH THE SPARE TIRE CARRIER

The spare tire carrier has two holes on either side as shown in the following photo.



With the rear cargo door open, from the rear side of the spare tire, reach inside the open cavity of the spare tire and into the side holes to pull the bungee hooks through both sides.



STEP 6 - SECURE BUNGEE HOOKS



Secure the bungee hooks to one another on top of the spare tire carrier's center support as show in this photo.



Close the rear cargo door and enjoy your new Wheel Shield!